


## Robertson Cypress Chest Harness CRC-203

CRC203-Small (red) CRC203-medium (blue) CRC203-large (gray)

For your own safety, please read and understand all information included with this product. Retain the instructions for future use and reference as needed. Provide this sheet to anyone using or supervising the use of this harness



### Installation Instructions

- This harness is best put on as a vest so that the adjustable waist and chest straps are in front and the single blue loop is in the rear.
- This harness needs to be connected in the rear by a carabiner to the seat harness rear tie-in loop. Figure 3.
- The chest harness shoulder straps are then laced behind the seat harness waist belt, brought around and laced back through the buckle so that the shoulder straps are snug. See Figure 1.
- The front chest strap will slide up or down for a comfortable fit. Figure 2
- Adjust height and snugness so that the shoulder straps will stay on the shoulders in a dynamic fall. Figure 2
- At least 3 inches of web tailing must extend from the buckle once secured around the waist belt.
- To tie-in, simply tie through the colored loop provided in the back of the harness while also connecting to the back loop of the seat harness. See figure 2.

**Do not attempt to tie-in anywhere other than the intended colored belay loop or rear tie off loop.**

This product has been designed, tested, and manufactured in accordance with ASTM-F 1772 testing which meets PRCA/ANSI 1.0-1.3 and ANSI/ACCT 03-2016 standards in effect on the date of manufacture.

**Warning!** Never adjust the web tailing in the buckle to its absolute extended length, keep a 4 inch minimum requirement. Rock climbing, ice climbing, mountaineering and other related activities are extremely dangerous by their very nature. A mistake or accident may result in injury or death. It is the sole responsibility of the buyer and the user of all climbing equipment to get the proper instruction and to practice caution when climbing or otherwise using this equipment. Frequently inspect every piece of climbing equipment for possible damage or signs of wear. Climbing equipment cannot be expected to last forever, and it is up to the individual user to determine when to retire a piece of equipment.

**CLIMB SMART!** Seek qualified instruction, and take responsibility for yourself. Inspect this product regularly and retire it immediately if it shows signs of wear or damage. Do not attempt to use this product if you are not fully competent in its use and care. Treat this product as though your life depends on it. Improper use or care of this product can result in serious injury or death.